



Foot Sole Pressure Sensing Device And It's Usage In Barefoot Shoes: Fullsoul Runningpad



Arved Strauch, Chutong Ren, Kai Burian



Kai



"Walking is a man's best medicine."

- Hippocrates

Daniel Liebermann – Barefoot Running

- Evolutionary biologist and paleoanthropologist at Harvard University
- Humans are "born and evolved to run"
- Studied barefoot running vs. running in shoes
- Barefoot running could prevent pain and injuries



“Leave Those Calluses Alone”


- Calluses are natural and necessary
- Calluses protect the sole of the foot **without** sensory loss
- Barefoot shoes like fullsoul: further protection **without** sensory loss




Fullsoul Runningpad




Barefoot Running – Tarahumara




Marathon Monks Of Mount Hiei, Japan



Barefoot Runner Abebe Bikila Wins Olympics




Motivation Funnel





Our Sensor


- Friend visited the manufacturer in China, got a demo model of a Velostat sensor
- Piezoresistive effect: changing resistance with applied pressure
- 156 different electrodes processing data at 200 Hz
- Controller sends data to PC over serial port




Proof Of Concept: Velostat Matrix



Proof Of Concept: Schematics




Proof Of Concept: Model



Sensor Hysteresis


Average Sensor Hysteresis During Loading and Unloading Processes



The peak hysteresis of the sensor reaches 24.6 units at 46g, accounting for about 9.8% of its output range (0-250).

Sensor Drift


Sensor Output Over Time (14g)



Sensor output surged from 28 to 47 in just 15 minutes, a drift of 7.6% of the total sensor output range (0-250).


Sensor Sensitivity

Sensor Output vs Pressure



Low sensitivity when the pressure is below ~ 3800 Pa; Curve becomes almost linear when the pressure exceeds ~ 10000 Pa.

Channel Crosstalk




The observed crosstalk typically ranged between 1 and 6 units out of 250


Fullsoul Sensor Integration



Fullsoul vs. Normal Shoe: Grass



Fullsoul vs. Normal Shoe: Stone Pebbles



Conclusion – What We Managed To Do




- ✓ Acquisition of raw sensor data
- ✓ Implementation of sensor in fullsoul runningpad
- ✓ Visualizing first test trials with fullsoul and normal shoes
- ✓ Initializing communications with the sensor manufacturer for further sensor acquisition

Feedback From Prof. Dr. Walther And Prof. Dr. Daumer

- Competitors in the medical field: Novel, Moticon do **not** possess the ability to be implemented with barefoot shoes
 - So far health benefits of barefoot shoes difficult to measure and usually require an intricate lab setup
- We might be on the way to develop a unique new technique to measure the benefits of barefoot shoes!

Future Outlook



Special Thanks



Prof. Dr. Martin Daumer



Prof. Dr. Markus Walther



Lingfeng Gu



Yuan Cao



Marco Busch

Want To Know More?

Find us on GitHub: <https://github.com/weichkai/footPressureSensor>

If you have a great idea or want to contribute to one of the future outlook tasks:

Contact us through E-Mail: footsolepressure.burian@tum.de